SmartWatch SmartPhone

操作指南



型号: EC308 / EC309(3G)
Printed V2.3 (2014) 简体中文

智能穿戴，从此开始

亲爱的用户，感谢您使用我们的智能腕戴手机！
为了您更好的使用这部手机，请在使用前仔细阅读本快速指南。

它是一台手表、手机、相机、录音机、收音机。
更是搭载了Android 4.0.4系统，集GPS、WiFi、G-sensor、蓝牙的全功能智能腕戴手机。

产品参数

Android 4.0.4智能系统
MTK6577（双核1.2G）
GSM 850/900/1800/1900MHz
WCDMA(3G) 850/1900/2100MHz (仅EC309)
RAM 512M，ROM 4G
1.54" TFT高清显示屏，RGB240x240 Pixels
OGS电容触摸屏
听筒 / 喇叭（二合一），麦克风
振动马达
摄像头300万像素
WiFi, GPS, G-sensor（重力感应器）
蓝牙, 7P miniUSB插口
GPRS, 短信, 彩信
音乐，视频，FM收音机，录音
环保聚合物电池，500 / 600mAh
产品尺寸: 41.9 x 47.5 x 13.5mm, 72.0g

GSM 4 Band · Bluetooth · GPRS · Wifi · GPS · Touch · Camera · Music · Video · FM Radio

包装配件

腕戴智能手机	x 1
USB适配器	x 1
USB数据/充电线	x 1
线控耳机	x 1
快速指南	x 1
micro SIM卡顶针	x 1

CCC CE FC RoHS COMPLIANT

使用须知

1 您的腕戴手机设计优良、工艺精湛，请精心护理。
2 请用指肚或者电容手写笔来操作触摸屏，避免尖锐的物体接触触摸屏；气温较低时，触摸屏反应速度可能较慢，属正常现象。
3 充电过程中，机体会有轻微发热，属正常现象。本机有温度保护装 置，以控制温度变化和充电安全。
4 电池的使用性能（待机时间和通话时间）因实际使用方式和习惯不同而有所不同。
5 手机可能受到无线电波的干扰影响通话质量。
6 本产品不防水，如果不小心进了水，请立即关机，待完全晾开后再开机。
7 请不要在灰尘较重、潮湿、高温的场合使用或放置本机，以免影响手机功能与显示效果，也可能影响电路安全与性能稳定。
8 请不要跌撞、敲打或激烈震动本机，否则可能毁坏机体结构与内部电路。

安全须知

1 本机及所有配件请放在幼龄儿童拿不到的地方， 以防出现吞噬意外。
2 交通行车安全第一，开车打电话时，请将手机戴在手腕上直接对讲，双手不要离开汽车方向盘，或者使用蓝牙耳机或者免提模式。
3 在飞机上请关闭手机或者启动飞行模式。
4 在加油站、油矿区、化工厂或爆破活动附近时，请严格遵守有关法规或条例，慎重使用手机。
5 只有本公司专业人员或指定维修机构才能拆装或维修本产品，自行拆装或维修可能带来损坏与危险。
6 只能使用经过本公司认定的配件和电池，否则可能导致手机功能障碍。

本快速指南所有插图仅供参考，具体以实物为准。
产品如有改良更新，恕不另行通知。

产品概览



micro SIM（手机）卡

请在关机状态下安装或取卸micro SIM卡，按以下图示。取卡时，请用SIM卡顶针向内顶压SIM卡，SIM卡将会自动弹出。



本产品仅能使用标准的micro SIM卡，或者通过剪卡器剪切，剪切时请确保SIM卡剪切边整齐，无披锋与翘边，否则有可能影响SIM卡的安装与取卸，甚至影响功能。

micro SIM（手机）卡

温馨提示：
EC308 只支持GSM网络
EC309 只支持GSM与WCDMA 3G网格
(以上两种型号均不支持 CDMA)



充电与USB

请在首次使用的时候，保证手机有4小时以上的充电时间，这样有利于激活手机电池的最大性能。
手机的USB插口除了充电外，也可以进行数据传输、下载，也能用于连接线控耳机。
请尽量使用原装USB数据充电线与线控耳机，否则可能出现不匹配问题。



按键



开关机键
1. 点击该键可以开启或者关闭显示屏。
2. 长按该键可以进行开机或者关机。

返回键
1. 点击该键可以退出当前应用程序或者返回上级菜单（或目录）。
2. 长按该键可以调出音量控制器（多媒体操作时）。

虚拟功能菜单键
在某一应用界面，点击显示屏上方状态栏中的 可以调出该应用的功能菜单。

温馨提示:
"点击"意为按击时间为1秒左右.
"长按"意为按击时间为3秒左右.

选择其它时钟界面



快速操作



桌面管理

认识桌面与瓷块
1. 手机桌面有各种瓷块，每一个瓷块可作为一个快捷方式，可以链接小部件、应用、快捷方式、文件夹等。
2. 每个瓷块的位置、大小、图标、背景色等可以任意编辑，瓷块之间的间距也可以任意设置。
3. 在桌面可以增加或者删除瓷块，也可以更换桌面主题。
4. 更多桌面管理功能，请进入桌面管理菜单。



瓷块更多尺寸可选择



编辑瓷块
长按桌面，可以进入桌面与瓷块编辑状态，轻点某一个瓷块，该瓷块三个角会分别出现编辑图标。此时也可以任意拖动该瓷块到桌面任何位置。



文件夹瓷块
1. 桌面文件夹方便您整理桌面的瓷块与应用。
2. 点击文件夹瓷块，添加应用或快捷方式到文件夹中。
3. 您还可以增加更多文件夹，也可以选择文件夹的显示风格。



更多桌面编辑
本产品提供两种方式进入更多桌面编辑
1. 通过"桌面管理"瓷块进入
产品出厂时，桌面向下第二页左下角瓷块默认为"桌面管理"，点击此瓷块可调出桌面管理菜单。
2. 划屏快捷进入
在桌面任何界面，手指从左向右水平划显示屏，显示屏下方会显示桌面管理菜单。



桌面主题
1. 桌面的瓷块设置、墙纸的设置等综合起来，我们称之为桌面主题。系统自带数种基本主题 ，可作参考。
2. 您可以自行编辑与设置桌面，并保存为自己的桌面主题，这将是您原创的独一无二的主题。
3. 瓷块删除后不能直接还原，您可通过主题还原或者重新添加。

桌面与程序窗切换
1. 在桌面任何界面，手指从右向左水平划显示屏，可以进入程序窗。
2. 在程序窗任何界面，手指从左向右水平划显示屏，可以进入桌面。



程序窗管理

程序窗设置
通过左划屏调出程序窗设置菜单，您可以进行以下操作



应用编辑
在程序窗长按某一个应用图标，系统会弹出编辑菜单
1. 系统自带程序，可以"添加到桌面"与"隐蔽该程序"。
2. 安装的第三方程序，可以"添加到桌面"、"隐蔽该程序"与"卸载 "。



软件更新与升级

1. 您可以到Google Play等安卓应用市场下载各类应用。（注：由于显示分辩兼容性问题，可能部分应用不能正常使用，请选择性下载）
2. 本产品软件可能进行不定期升级，敬请关注我们的官方通报信息，或者向您的销售商进行相关咨询。
3. 本产品支持用户自行开发更多专业应用，开发前参阅与产品有关的规格与参数。



您的智能手机支持OTA一键升级，
您将免费享受我们的持续升级服务。

感谢您的耐心阅读!
如果您有任何疑问或建议，请联系您的销售商，他们将会热情为您服务。

智能穿戴，智能生活

由于这是一台与您 "人机合一"的穿戴设备，基于其与您亲密接触、携带方便等特点，哈波公司将致力于以下五大领域的应用开发：

- 为了您的科学运动
运动量监测、运度强度分析、速度监测等
- 为了您的户外活动
温度、湿度、海拔、气压、紫外线、噪音、光线强度、风速等监测，以及指南针、对讲等户外辅助功能
- 为了您的医疗健康
心率、脉博、体温、血压等监测，并将与医疗中心联网
- 为了您的人身安全
GPS定位、跌倒监测与SOS呼叫、行动轨迹、电子围栏等
- 为了您的智能生活
NFC、RFID、PayWave、智能家居等

由此可见，它不是一台普通的手机。
而是一台与您的生活密切相关的智能穿戴设备。
但由于不同的应用需要不同的硬件与软件支持，
您的这台设备可能无法享受以上所有的应用。
请根据您的实际需求，关注我们相关产品与新应用发布。

SmartWatch SmartPhone



Quick Start User Guide

model: EC308 / EC309(3G)
Printed V2.3 (2014) English

Smart wearing, Smart life

Dear User, thank you for using our smart watch phone, please read this Quick Start User Guide Carefully before use.

It's a Watch,Phone,Camera,Recorder,FM and Music Player. Android 4.0.4 Smart Watch Phone with WiFi-GPS-Bluetooth.

Specification

O.S. Android 4.0.4
MTK6577 (Dual Core)
GSM 850/900/1800/1900MHz
WCDMA(3G) 850/1900/2100MHz (EC309)
RAM 512M, ROM 4G
Display 1.54",TFT, RGB240x240 Pixels
OGS capacitive touch screen
Speaker / Headphone (2 in 1)
Microphone / Vibration Motor
Camera 3.0MP
Wifi, GPS, G-sensor
Bluetooth, miniUSB Port, Hands free
GPRS, Music, Video, FM Radio
Voice recording, SMS, MMS
Lithiumion battery, 500 / 600mAh
41.9 x 47.5 x 13.5mm, 72.0g

GSM 4 Band · Bluetooth · GPRS · Wifi · GPS · Touch · Camera · Music · Video · FM Radio

Content in Box

Smart watch phone	x 1
USB adapter	x 1
Micro USB cable	x 1
High quality headset	x 1
Quick start user guide	x 1
Micro SIM card ejecter pin	x 1

CE FC RoHS COMPLIANT

The illustration in this quick start user guide is for reference only
Please refer to the actual product

Read Before Use

1 Your phone has been delicately designed and made, deserves to be taken good care of.
2 Do not use sharp objects to operate on touchscreen; when temperature is low, touchscreen will be less responsive, which is normal.
3 The product may be slightly warm when charging, which is normal. The product is equipped with temperature control system to ensure charging safety.
4 The product standby time and talk time may vary based on how the product will be used and different use habits.
5 The call quality may be influenced due to radio wave interference.
6 This product is not waterproof, please prevent water from entering watch, (if water entered, please switch off the phone immediately; use the product only after water completely dries up).
7 For better performance & display effect, do not use or place the product in dusty area.
8 If need to use other adaptor, please make sure its output voltage and current matches the original one.
9 Due to plug definition being different, other charging cable or earphone may not be compatible to use.

Safety Instructions

1 Keep the product & all accessories out of children's reach to prevent accidents.
2 Before driving, please prepare wired headset (or Bluetooth Headset) ready or switch to hands-free mode.
3 Turn off your phone on the plane or switch to flight mode, otherwise it may cause interference to the plane.
4 Use mobile phone very carefully when in gas station, oilfield, chemical plant or other hazardous areas, stick to the relevant regulations & terms.
5 Do not place the product in high humidity or high temperature area, otherwise the electric circuit may be interfered.
6 Please use and keep phone battery safely; When not using the product for a long period of time, please take the battery out of product.
7 Only our professional staff or assigned repair centre can disassemble or repair the product; trying to disassemble or repair by oneself may cause damage.
8 Use only accessories & battery approved by our company, otherwise it might cause trouble or damage to the phone.

Phone Overview



Micro SIM card

Please insert/take out micro SIM card only when the phone is switched off. Please insert micro SIM card into the card slot as per illustration shows, then use ejector pin to push micro SIM to the end.



(If the micro SIM has not been pushed to the end, it will be ejected out)
This product is only compatible with standard size micro SIM card. Please turn to network provider or use a micro SIM cutter.

micro SIM card

EC308 only supports GSM
EC309 only supports
GSM and WCDMA
(does not support CDMA)

Charging

For the first 3 charges, make sure to drain the battery before charging, and charge at least 4 hours. This will activate the battery to its best performance. The USB port could be used for charging, data transfer and earphone connection.



Buttons



Home button
1. Press button to light on/off display.
2. Press & hold button to power on/off.

Back button
1. Press button to Exit current application or back to previous menu.
2. Press & hold button to activate volume controller. (for Multi-media appliation)

Note:
Press:1s
Press & hold: 3s

Visual button
Under one APP's interface, press the visual button on the top right corner of display to enter the APP's function menu.

Choice other clock face



Operation Guide



Desktop Management

Know more about desktop and C-blocks.
1.There're many color blocks likes ceramic blocks on the desktop , so we called them C-block. each C-block functions as a shortcut, which could be linked to widget, app, shortcut or file folder etc.
2.Location, size, icon, background color of each C-block could be customized freely; also distance between C-block could be set.
3.User could add or delete any C-block from desktop, also could change theme of the desktop.
4.For more desktop management info, please enter desktop management menu.



More C-block size for you to choose from.



Edit C-block
Tap and hold on desktop will enter editing mode for desktop and C-block, tap any C-block and you will see editing mark on three edges of the C-block. Meantime, you could drag this C-block and place it anywhere on the desktop.



File folder C-block
1.File folder C-block will make it easier for you to manage apps.
2.Tap file folder C-block, you could then add apps to the file folder.
3.You could add more file folders and choose it's style you like.



More desktop editing
You could enter more desktop editing through these two methods:
1.To enter through 'Desktop Management' C-block:
In default setting, there's 'desktop management' C-block on the lower left corner of desktop, tap this C-block could enter desktop management menu.
2.Sliding Shortcut to enter.
Under any desktop interface, horizontally slide from left to right on the screen, you will then see the desktop management menu showing up on the bottom of screen.



Desktop Theme
1.The overall setting for desktop C-block and wallpaper etc, we call this desktop theme. There're several basic themes included in the software, which you could treat as reference.
2.In default setting, there's theme C-block on the lower right corner of desktop
3.You could freely edit and set desktop, and save as your personal desktop theme, this will be your original & unique theme.
4.C-block could not be retrieved if it's been deleted. Please use the theme retrieve function to retrieve the deleted C-block or add a new C-block.



Switch between desktop and apps window
1.Horizontally slide from right to left ,will enter apps window.
2.Horizontally slide from left to right, will enter desktop.



Apps Management

Apps window settings
Under apps window ，horizontally slide from right to left，you can perform the following operations.



App edited
Under apps window ，tap and hold on an app icon, the system will pop up the edit menu.
1.If the app installed in system , it can be edited "Add tile" and "Hidden".
2.If the app installed in third party, it can be edited "Add tile" . "Hidden" and "Unload" .



Updating the software

1. You can download kinds of Apps from Google Play (Note: may be part of the Apps cannot be used normally due to screen resolution compatibility issues.)
2. The software structure may be changed in the new version software, or more applications would be made available, please read the version instruction then.
3. This product supports customers' self-developed APPs or Gadgets; if you're a developer, please refer to the products' relevant specification & parameters.



Your smart watch phone supports OTA one-click update, you will be entiled to enjoy our consistent software update service.

Thank you for choosing our product!

Should you have any questions or concerns, please contact the retailer and they will do everything possible to assist you.

Connecting the future

This product is Android Based Smartphone Watch, so you can install many APPs just using an ordinary smartphone. Meanwhile, considering watch phone' s special features:

Direct contact to human body / Easy to read & check

we will mainly concentrate in developing special apps in the following areas:
1. Scientific exercise management
Exercise amount and Intensity monitoring, Speed monitoring
2. Convenient outdoor activities
Temperature, Humidity, Altitude, Barometric pressure, UV radiation, Noise, Light intensity, Wind speed, Compass and Walkie talkie function
3. Health management
Heart rate, Pulse, Temperature, Blood pressure etc monitoring, Furthermore we can consider to connect device to the medical care center.
4. Your safety management
GPS positioning, Falling-sensor and SOS alarm, Movement tracing records, GEO- fencing etc.
5. For other smart life
RFID, PayWave, Smart household applications

As you can see, it is no longer an ordinary mobile phone, it's an intelligent device that associates with you closely.
Note: The product you're holding in your hand may not support above all functions, because some functions may need backup from product hardware. We will continuously release many new products for you to choose from.
Please stay tuned!